

In this tutorial, you will learn how to browse channels using the Channel Banner and the Navigator interactive on-screen guide.

Channel Banner:

Quick Program Information

1. When you change channels, the **Channel Banner** appears automatically at the bottom of your screen.
2. You can also display the **Channel Banner** any time by pressing **INFO** on your Digital Remote.
3. The banner tells you which channel you're on, the title of the show you're watching, the current time, when it started, and when it ends.

Browse Listings

While the **Channel Banner** is up on the screen, you can browse other program listings without leaving the show you're currently watching:

1. Press the **UP** or **DOWN** arrows to display information for shows playing on other channels.
2. Press the **LEFT** or **RIGHT** arrows to display information for shows playing at other times of the day.
3. The information for the show you're currently watching stays on screen, but moves to a smaller bar.

Get More Info

1. If you find an interesting program, you can get more information by pressing **INFO** again. At the bottom of the screen, you now see a full description of the program.
2. If there is more than one page of information, you will see the **PAGE+/-** symbol. This lets you know that you can press **PAGE+/-** to get to the next page.

Select a Program

When you find a program you like, press **SELECT** to tune to it instantly.

Exit the Channel Banner

If you prefer to keep watching your original program, press **EXIT** to exit the **Channel Banner**.

Navigator Interactive On-Screen Guide Detailed Program Listings

1. Press **GUIDE** on your Digital Remote to display the **Navigator Interactive On-Screen Guide**.
2. The show you're currently watching will shrink to a small window in the top right corner.
3. The channel guide will appear at the bottom of the screen showing what's on TV at other times of day or other channels.
4. In the top left of the screen is a description of the highlighted show.

Browse Channels

1. To see what is on other channels, use the **UP** or **DOWN** arrows. Or, enter a specific channel number and press **SELECT**.
2. To see what's on at other times of the day use the **LEFT** and **RIGHT** arrows to see what is on at other times of the day.

Note: As you scroll through programs, the information in the upper left will change to describe the highlighted program.

— continued —

— continued —

Get More Info

1. When you find a show you're interested in, press **INFO** to get more information, such as a longer program description, actors, and program rating.
2. Press **INFO** again to return to the program guide.

Select a Show

When you find a program you like, press **SELECT** to tune to it instantly.

Exit the Navigator interactive on-screen guide

To keep watching your original program, press **EXIT** to return to it full screen.