

What is a Universal Remote?

Your Digital Remote is a Universal Remote that can control your Digital SmartBox, TV, VCR and Stereo (on some models). This allows you to control all your equipment without using separate remote controls.

In order for your Digital Remote to work on all your equipment, your Digital Remote must be programmed for your own equipment.

How to Program Your Digital Remote

1. Your Bright House Networks installer may have already programmed your Digital Remote for some of these functions. If this is not done, you can program your Digital Remote yourself. You may also need to program your Digital Remote if you move your TV, get new equipment, or the batteries in your Digital Remote expire.
2. For complete instructions, view the specific user manual for your Digital Remote. You'll get the codes for your specific brands of equipment and step-by-step instructions. If you have any problems, call Customer Care.

Using Your Digital Remote

Once your Digital Remote is programmed, you can use it for all of your equipment:

1. Press **VCR** to control your VCR.
2. Press **CBL** to control your Digital SmartBox.
3. Press **TV** to control your TV.
4. Press **AUD** to control your stereo receiver.

Note: **AUD** is not available on some models.